



- | | |
|---------------------------------|---|
| 1. DOME COVER | 12. CONTROL SURFACE |
| 2. GUIDANCE AND CONTROL SECTION | 13. ROCKET MOTOR IGNITER CABLE |
| 3. CENTER-AFT SECTION | 14. ROCKET MOTOR |
| 4. CENTER SECTION | 15. SAFE-ARM KEY (IN ARM POSITION) |
| 5. FORWARD HOOK | 16. SAFETY ARMING DEVICE |
| 6. FUZE/BOOSTER ASSEMBLY | 17. BATTERY |
| 7. AFT HOOK | 18. FUZE DELAY SELECT UNIT |
| 8. UMBILICAL | 19. WIRING HARNESS |
| 9. UMBILICAL ADAPTER | 20. WARHEAD |
| 10. HYDRAULIC ACTUATION SYSTEM | 21. ACTUATOR CONNECTOR/CONNECTOR CAP |
| 11. GAS BOTTLE | 22. GUIDANCE AND CONTROL SECTION WINDOW |

Figure 3. AGM-65E Laser MAVERICK Missile Components.